

#### **TP-590RXR Quick Start Guide**


This guide helps you install and use your product for the first time. For more detailed information, go to <u>http://www.kramerav.com/manual/TP-590RXR</u> to download the latest manual or scan the QR code on the left.

# Step 1: Check what's in the box




Power adapter (12V DC)

- 8 Rubber feet
- 🗹 Quick start guide



## Step 2: Install the TP-590RXR

Mount the device in a rack (using the optional rack adapter available for purchase) or stick the feet to the underside and place it on a shelf.



### Step 4: Set the DIP-switches

A DIP-switch that is down is on, up is off (default)

#	Feature	Function	DIP-switch
1	Extended Range	Enables extended range when used with either the TP-590TXR or other transmitters that support extended range	On—Enable Off—Disable
2	Reserved		
3	EDID Lock	Locks the current EDID and prevents automatic EDID acquisition	On—Lock EDID Off—Automatic EDID acquisition
4	Reserved		

#### Step 5: Connect the power

If the **TP-590RXR** is not connected to a **TP-590TXR**, connect the power adapter to the **TP-590RXR** and plug the adapter into the mains electricity.

TP-590RXR Quick Start (P/N: 2900-300500QS REV 1)

